

CHEMICAL PROCESSING

LEADERSHIP | EXPERTISE | INNOVATION



Compressed AIR

ENERGY SAVINGS ARE OFTEN OPPORTUNITIES DISGUISED AS PROBLEMS

Carefully managing your compressed air can save money

Compressed air is often overlooked in energy studies because many people do not fully understand compressed air equipment, their own system, or what it costs to produce compressed air power. For those willing to look, and use some good old common sense, it is a land of opportunity. Just how expensive is compressed air? It takes about 8 hp of electrical energy to produce 1-hp-worth of work with compressed air. Using compressed air to cool electrical cabinets — a typical application — makes no sense!

Here's some food for thought:

- 1 cubic ft. per minute (cfm) cost - \$100 per year in energy cost;
- 2 psig cost — \$398 per year in energy cost for every 100-hp;
- 50% of the compressed air generated is lost to production (Figure 1).

The values are based on some assumptions: a compressor operates 8,000 hours a year; the cost of electricity is \$0.06/kWh and the compressor produces 4.0 cfm at an expenditure of 1 hp (brake horsepower) at a discharge temperature of 100°F and 100 psig. Considering the recent rise in energy costs, an audit of the compressed air system could yield significant savings. Based on years of Level One and two plant surveys (Level one: equipment supplying air, e.g., compressors, dryers, etc. Level Two: equipment using air.), we expect that a Level One audit will identify a number of problems with air systems. Here is what we typically see:

1. Ignoring the electrical cost of compressors;
2. Pressure losses;
3. Air leaks;
4. Running the header pressure higher than

required;

5. Pressure regulators operate full open (because they work better that way!);
6. Inappropriate uses for compressed air;
7. Not recovering heat;
8. Inadequate or poor maintenance;
9. Not measuring air usage.

Ignoring the cost

There is more to a compressed air system than pipes and a compressor. There is the supply side of the system and the demand side. The supply side may consist of an inlet filter, compressor(s), an after-cooler, a dryer, a receiver, and header piping. Never mind the fixed costs! It takes skilled labor, and electricity. Chilled water may be required for the after-cooler and dryer. Just operating a 100-hp compressor 24/7, 47-weeks/year will cost about \$43,000/year (\$0.06/kWh, 90% motor efficiency).




Figure 1. It is not unusual for 50% of the air to be wasted in plant compressed-air systems.

cy) in electricity alone. The demand-side is every application where air is used. A solenoid valve that stays open most of the time could cost you as much as \$9,000/year — this is a demand-side loss. Your system works best when the flow and pressure produced by the supply side match the optimum conditions, i.e., minimum flow at lowest pressure, required by the demand side. Without a complete audit, how will you know what your real costs are?

Pressure losses are costing you money!

There are unnecessary losses on the supply side and on the demand side. Causes are: undersized equipment such as dryers and filters, undersized piping, dog-legs, crossing tees, and condensation (oil and water). In a well-designed system, the pressure drops in the piping before the dryer, and after, and to the header, should be *zero*; the velocity throughout the system should be less than 20 ft. per second (fps). The dryer and filter should have a drop less than 2 psig — together. If you don't meet any of these conditions, then you are wasting power and disrupting the unloading controls on your compressors. This can be expensive: a reciprocating compressor can run at 0% power in the unloaded state; a screw compressor uses some power in this state. Some common pressure losses are shown in Figure 2.

Compressed air leaks

After you have addressed problems with your layout, it is time to look at the next ranking problem: leaks. Thirty percent, or more, of lost air in most facilities is from leaks! It takes a cooperative effort to eliminate this cost. You need a leak management program involving maintenance *and* production. We suggest a plan with short-term and long-term objectives.

The goal of the short-term program is to determine which areas of the facility have the




Figure 2. A few changes to your layout will cut your electric bill.



Need to know more about compressed air?

For your completely free 156 page guide - Please send an E-mail with subject line CP Manual to paul.humphreys@us.atlascopco.com

866-688-9611




Figure 3. Use a booster for high equipment such as this filter press instead of keeping the entire system at high pressure.

most leaks. Short-term means a year, with audits every three months. Inspections should be conducted with an ultrasonic leak locator when the plant is running and when it isn't.

Goals for the long-term program are broader: educating personnel in operations and maintenance to identify and repair leaks. A material balance should be established for the plant and developed so air use for each department can be defined. Test the balance and update it! Providing incentives for conserving air can help drive down costs.

High header pressure

Every process in your plant that uses compressed air has a minimum pressure required to operate effectively. Except for the pressure drop in the delivery system, which should be minimized, extra pressure is a waste. Lower the pressure, save energy, right? Not when the perceived minimum pressure is high. The politically correct approach is to measure the equipment air flow and pressure required at the demand source. Once this is done, installing a receiver (a small vessel between the regulator and the process) or eliminating a restriction should help you find the real minimum.

What if a high pressure really is needed? You may want to supply the local high-pressure need with a secondary, smaller, "booster" rather than drive the whole system at a higher pressure. The filter press (Figure 3) required a 100-psig mini-

mum while the rest of the chemical plant ran well on 90 psig.

Pressure regulators operate full open

Often the process regulator is wide open at the header pressure because the "droop" wasn't allowed for. The regulator may be correctly sized but the gulp of air required is more than the line can supply. If, during the delay, there isn't enough volume to hold the demand pressure, then the pressure falls. Production is negatively affected and the operator opens the regulator up to full line pressure. This is called "artificial demand."

A fix for this problem is a receiver. This will hold the pressure until the regulator opens. One example is an air-driven agitator used for a settling pond. Three minutes of agitation at 150 cfm are required every 30 minutes to promote digestion. The pressure drop, measured for the cycle, is from 90 psig to 40 psig. The total air, based on the inlet pressure, required for agitation is 450 ft³ (3 minutes × 150 cfm). Therefore, the volume of the receiver should be at least:

$$V_R = (450) (14.7) / (40) = 165 \text{ ft}^3$$

Inappropriate uses for compressed air

This can be the most difficult problem to solve. The previous example could represent an in-




Figure 4. Thermoelectric refrigeration works by forcing electrons to overcome resistance.

Equivalent Uniform Annual Cost (EUAC) ⁽¹⁾						
	Compressed air		Alternative			
Application	Comment or limitation	Cost	Alternative-best	Comment or limitation	Cost	Savings
Cabinet cooler -1500 BTU/hr ⁽²⁾	T<90°F ⁽³⁾ ⁽⁶⁾	\$28,250	Thermoelectric refrigeration	T<140°F ⁽³⁾	\$490	\$27,760
			Vortex tube	T<200°F ⁽³⁾	\$2,130	\$26,120
			Heat pipe	T<90°F ⁽³⁾	\$260	\$27,990
			Std. refrigeration	T<135°F ⁽⁴⁾	\$2,810	\$25,440
			Ambient air fan	T<70°F ⁽⁵⁾	\$630	\$27,620
Blowing air ¼ in. tube	Open-end ⁽³⁾	\$3,820	Venturi nozzle	⁽³⁾	\$1,210	\$2,610
Pump 130 gpm @ 40 TDH	2 in. Air diaphragm pump ⁽⁵⁾	\$16,240	5-hp electric chem. pump	Centrifugal ⁽⁵⁾	\$7,120	\$9,120
Hoist 2.5 ton	Air hoist 4.25-hp ⁽³⁾	\$2,540	Electric hoist	⁽³⁾	\$740	\$1,800
Vibrator in continous service	Air vibrator 7 cfm @ 80 psig ⁽⁵⁾	\$1,280	Elect. vibrator at 2 A current	⁽⁵⁾	\$860	\$420
Agitation	Sparger 80 psig ⁽³⁾	\$6,650	Sparger with 10 psig blower air	⁽³⁾	\$1,930	\$4,720
			2-electric agitators, 1-hp	Portable ⁽⁵⁾	\$1,620	\$5,030
Notes:						
1. Interest rate: 10%; straight-line depreciation 2. Electric cost: \$0.06/kWh. 3. Equipment life: 10 years. 4. Equipment life: 2.3 years. 5. Equipment life: 5 years. 6. Generally, above the temperature limit, the alternative will not provide cooling.						
Table 1. Compressed air is often by far the most expensive option for a service.						

appropriate use of compressed air if electrical power is available. Some other applications could be:

- cooling for electric cabinet;
- vacuum (eductors);
- blowing, or blasting;
- pumps (air-diaphragm);

- air hoists;
- air vibrators; and
- sparging (agitating with air);

Table 1 summarizes typical savings possible by eliminating inappropriate uses of compressed air. Some applications, such as using an air eductor, or ejector, to prime a suction-

866-688-9611



Time for a free compressed air audit?

Register on-line at www.atlascopco.us/mboxusa

lift pump require compressed air only periodically. Still, it is worth noting that to produce 10 in. of Hg vacuum, at a flow of 10 cfm educted air (14.7 psia, 70°F), requires 8 cfm of compressed air (100 psig, 100°F). Often eductors are hard to replace with electric-driven vacuum pumps. Eductors can pump a corrosive fluid and pose lower risk in an intrinsically safe environment.

For other applications, such as cooling electric cabinets, it's easier to justify less-expensive alternatives. Cabinet cooling is often required to prolong the life of electronic equipment. Compressed air seems like a tempting choice. However, it's apparent from Table 1 that it doesn't make economic sense. There are several cost-efficient methods of cooling that are available, including vortex cooling, heat pipe, thermoelectric refrigeration, ambient air, and standard refrigeration.

In vortex cooling, compressed air is chilled

by expansion and bled into a cabinet. Hot air in the cabinet is educted to the outside by the flow of the chilled compressed air. To economize on air and prevent condensation of moisture, vortex units should be equipped with an automatic temperature shutoff. Although the cost saving isn't as significant as it is for other alternatives, such as heat pipe and refrigeration, vortex cooling works up to 200°F.

The heat pipe is another substitute for compressed air. Cores of a heat pipe are made of a highly conductive material for cooling. As in a refrigerator, heat is transferred by changing the phase of a liquid. Heat is absorbed by the core, inside the cabinet, and passed to the fluid inside the pipe. The fluid is vaporized and flows outside of the cabinet where it is condensed. In the air-cooled version, an exterior fan draws heat away from the core, which cools the internal cabinet without exposing the interior to ambient air.




Figure 5. Cooling needed for air compressors can be turned into heating savings.




Figure 6. Dirty inlet piping wastes \$45,000/year.

The fluid is condensed and returned to the core inside the cabinet for another cycle. The air-cooled version is limited by the ambient temperature of the outside air. The heat pipe offers the best economic choice, where physical limits allow (Table 1).

Thermoelectric refrigeration offers the greatest flexibility and has the second lowest annual cost. This type of refrigeration operates using the Peltier effect: when two dissimilar metals or semiconductors are connected together, current drives heat from one terminal to another. Refrigeration units consist of an array of p-type and n-type semiconductor elements connected (Figure 4). Heat is carried by electrons, in the n-type, and the holes created by electrons, in the p-type. The heat pumping capacity of a module is proportional to the current and is dependent on the element geometry, the number of couples, and the material properties. Current technology is limited; 1,500 BTU appears to be the largest available — now.

Other options for cabinet cooling have their own niche. Fan cooling and standard refrigeration can certainly compete for large cabinets. Fans are limited by ambient air temperature but are inexpensive. One unique place for fans is in coolers or other areas that

are already cooled. Refrigeration may be the only choice for large cabinets in hot zones.

Blowing cash away

Another common waste of compressed air, apparent to anyone who has visited a packaging area, is the use of air to blow products or dust. A ¼-in. line will flow 32 cfm at 80 psig. An open-ended blow tube represents an annual loss of more than \$3,800 (Table 1). Regardless of the application, several guidelines should be applied to compressed air being used for open blow-off: 1) use anything else whenever possible; 2) use low pressure air from a blower — the lower the pressure

Atlas Copco

866-688-9611

So what's the secret behind the pipe?

www.airmet-system.com




Figure 7. Install a loop to balance the load on the system.

the lower the cost; 3) regulate the flow to the lowest effective pressure — know the pressure! 4) use a venturi nozzle or air inducer to reduce compressed air used; and 4) shut-off blow-off air (automatically) when not needed for production.

Air amplifiers, or inducers, will reduce compressed air flow, where a mechanical method, such as a wiper, cannot replace blow-off. Air amplifiers use “venturi” action to pull in ambient air and mix it directly into the compressed air stream. The ratio of ambient air drawn in can be substantial. Amplification ratios up to 25:1 are possible. Using 10 cfm of compressed air can produce up to 250 cfm of blow-off air. This is a savings of 15 cfm of compressed air per ¼-in. blow-off.

Although air-operated diaphragm pumps are not very energy efficient, they tolerate aggressive conditions well and are not seriously damaged if run dry. Also, they are not a serious hazard in intrinsically safe environments. If an electric pump — diaphragm, centrifugal or progressive cavity — can be made to work, it will usually be cost-effective. When an air-diaphragm pump is the still the best choice, reduce the utility costs by either shutting off the air if the pump is not needed, or lowering the supply pressure. Generally, when a pump must operate for long periods, an electric

pump will save money over an air-diaphragm pump (Table 1).

Air hoists and air vibrators are sometimes chosen when electricity is not available or where the area is intrinsically safe. This safety issue is generally not a concern with pumps and agitators where isolation is easier. Hoists and vibrators pose other concerns. Air hoists used only occasionally have a high incidence of unnoticed air leaks. High pressure air is required by air vibrators to be effective; economically, they are often a poor choice — except where small size is needed.

Sparging with air may be necessary if the product is sensitive, e.g., friable, or where mixing mechanically is not economical or practical. One example where mechanical mixing might be uneconomical would be where a tank is very long, requiring an agitator with a long shaft. Another would be where air is available but electricity is not. If mixing by sparging is the best solution, doing so at the lowest possible pressure reduces the cost (Table 1). Use low-pressure air supplied by a blower, if available. Use a step-down regulator on compressed air, if only high-pressure air is available.




Figure 8. In a poorly managed system, power usage doesn't respond to change in demand.

Not recovering heat

Compressing a gas generates a lot of heat. However, 85% to 90% of the motor horsepower used to run a rotary screw air compressor can be recovered in the form of heated air or water. Similar recovery, in the form of heated water, is possible with water-cooled compressors. It takes 8 hp of electrical energy to produce 1 hp of air power. *That means that a portion of the 7 hp of unused energy is available as heat.* Recouped heat can be used in many ways: 1) space heaters; 2) heating process water; 3) boiler make-up; 4) and running a “heat of compression” desiccant dryer. Figure 5 depicts a typical reclamation system for a compressor.

Fix it when it breaks

This seems to be the modus operandi with utilities. Too often maintenance on compressed air is viewed as an expense when it is really an opportunity for savings. Maintenance on the supply side has a direct impact on plant energy use.

On a recent audit, we found a compressed air system sorely in need of basic maintenance (Figure 6). Dirty inlet filters lowered the inlet pressure from an expected 14.2 psia to 9.5 psia. This reduced the air production from each rotary screw compressor from 725 scfm to 501 scfm — a loss of 31%. All three compressors were run at full load to supply the 1,400 scfm demand. Correcting this problem saved \$45,000/year in electricity.

Audits also are useful in identifying residual design errors. Figure 6 shows two typical errors. First, a riser after the dryer could collect condensate, which can cause a drag on gas flow. Normally, dips in piping are allowable but should include a receiver and condensate trap; a riser at the dryer discharge is an exception. The second error is the use of tees instead of wyes. Another potential sav-




Figure 9. In an optimized compressed air system, power responds to demand, saving money.

ings overlooked is using outside air (cold air is denser than heated air).

A high pressure drop in filters and separators is a problem we see a lot. If you knew what power costs per psig, then you would probably re-evaluate your schedule for changing separators and filters. A typical pressure drop for a new oil separator is 2-3 psig. After two years, the pressure drop may be 10-12 psig. With the cost of \$200/year per 1 psig (\$0.06/kWh), and assuming replacement elements cost \$550/each, it is prudent to change the elements somewhere between 3-4 psig.

Measurement

If you don't measure it, you can't manage it! Do you have a material balance for compressed air? Are the minimum flow and minimum pressure documented for all of your equipment? Are you monitoring your compressor cycle times and power usage? Is anyone keeping track of tie-ins for new equipment or do you have a single 1-in. pipe feeding five packaging machines when a separate line should have been built for all five machines? Do you have flow meters installed at key points in your piping network — if so, when were they last calibrated? Most of the

Atlas Copco

Time for a free compressed air audit?

Register on-line at www.atlascopco.us/mbxusa

866-688-9611



plants we have audited have flow meters on the main air supply but few in the production areas, with calibration every 10 years, whether they need it or not! As for pressure, we generally find that no test points or gages are installed in critical interconnecting pipes.

What can you do to initiate a plan for monitoring your compressed air? Install test points for pressure gauges at the compressor discharge, before the pre-filter and dryer, after the after-filter and throughout the demand side of the piping. This is especially true for loops where a series of equipment is supplied (Figure 7). Install flow meters at branches in the system. After you have installed flow meters, try to solve the material balance. Most of the time, you will find you missed something.

*Unless instruments
are periodically calibrated,
they will drift.*

Another common problem is gauge accuracy. Although it may be useful to install gauges to monitor pressures at the demand points, don't use these values in calculations! Unless instruments are periodically calibrated, and this goes for flow meters as well, they will drift. Because even calibrated gauges can differ in accuracy, measure differential pressures throughout the network with a single test gauge. For our purposes, we rely on high quality digital gauges. We use the same gauge, which has been calibrated prior to being employed. This is the only way to know what is going on.

Sometime during the discussion about a measurement plan someone will ask about measuring the dew point in the system. Technically, this is known as the pressure dew point (PDP). The damage that moisture causes to some equipment will be itemized as justification for a humidity meter. Generally, measuring the PDP is unnecessary. *If you have a moisture problem eliminate it!* Some

industries, such as pharmaceuticals, food, cosmetics and fine chemicals (refer to ISO 8573.1) may have air quality standards that require permanent monitoring of humidity. These instruments are delicate and need annual calibration.

A well-managed system

How do you know when your air compressor system is performing at maximum efficiency? Figure 8 shows a stable well-managed system. A conservation program is in-place, air quality meets standards, and pressure drops have been eliminated on both the demand-side and supply-side. The trouble is that the cost savings are impressive but the power usage is still a little higher than expected — what's wrong? Look at Figure 8. The chart shows that power doesn't respond to demand, i.e., flow: reduced demand should mean less power — right? What is needed is an air management system to assure that all compressors run at full-load efficiency. This system must have software capable of analyzing operating condition, compressor load condition, and adjusting to pressure change — either rise or decay. The net result will be all units on at full demand (load), one on at partial load, and all other off, 80% to 85% of the time. Figure 9 shows the results of installing a management system.

Another component of a well-managed system is keeping it in tune. This requires an annual check-up, and a monitoring system. Monitoring systems are available to do this on a continuous basis.

A final component is training. Operating and maintaining a compressed air system requires the efforts and talents of many people. To be effective, these people must understand how your system works and how interdependency of its components affects cost. It has been our experience that this type of training pays off quickly.

Energy savings go directly to the bottom line. Saving money in compressed air will not only reduce costs it will increase plant production.

COMPRESSED AIR SYSTEMS: THE SECRET IS IN THE PIPE

There's no such thing as too large a compressed air line. A common error in compressed air systems is line sizes too small for the desired air flow.

A common error we see in compressed air systems, in addition to poor piping practice, is line sizes too small for the desired air flow. This isn't limited to the interconnecting piping from compressor discharge to dryer to header. It also applies to the distribution lines conveying air to production areas and within the equipment found there. Undersized piping restricts the flow and reduces the discharge pressure, thereby robbing the user of expensive compressed air power. Small piping exacerbates poor piping practices by increasing velocity- and turbulence-induced backpressure. (See "There's a Gremlin in your air system and 'its name is turbulence,'" pg 37, *Plant Services*, July 2002).

Pipe size and layout design are the most important variables in moving air from the compressor to the point of use. Poor systems not only consume significant energy dollars, but also degrade productivity and quality. How does one properly size compressed air piping for the job at hand? You could ask the pipefitter, but the answer probably will be, "What we always do," and often that's way off base.

Another approach is matching the discharge connection of the upstream piece of equipment (filter, dryer, regulator or compressor). Well, a 150-hp, two-stage, reciprocating, double-acting, water-cooled compressor delivers about 750 cfm at 100 psig through a 6-in. port. But most 150-hp rotary screw compressors, on the other hand, deliver the same volume and pressure through a 2-in. or 3-in. connection. So, which one is right? It's obvious which is cheaper, but port size isn't a good guide to pipe size.

Charts and graphs

Many people use charts that show the so-called standard pressure drop as a function of pipe size and fittings, which sizes the line for the what is referred to as an acceptable pressure drop. This practice, too, can be misleading because the

charts can't accommodate velocity- and flow-induced turbulence. Think about it. According to the charts, a short run of small-bore pipe exhibits a low total frictional pressure drop, but the high velocity causes an extremely large, turbulence-driven pressure drop. Then, there's the question of the meaning of acceptable pressure drop. The answer to this question often isn't supported by data, such as the plant's electric power cost to produce an additional psig.

We've audited many plants during the past 20 years and found the unit cost of air for positive displacement compressors runs from several hundred dollars per psig per year to several thousand dollars per psig per year. At current energy costs, you don't want the pipe to be a source of pressure drop.

Shooting blind

Not knowing the energy cost of lost pressure as a function of line size can lead to a blind decision. Unfortunately, this is what we find in most of the air piping systems installed during the past 30 years. Older systems that were designed with care are often right on the mark, except if they've been modified after the original installation.

Some might call pipe sizing a lost art, but we see the issue as a lack of attention to detail, basic piping principles and guidelines. Read on to



Need to know more about compressed air?

For your completely free 156 page guide
Please send an E-mail with the subject line CP Manual
to paul.humphreys@us.atlascopco.com

866-688-9611

learn how to size air piping using velocity, which, when combined with appropriate piping practice, ensures an efficient compressed air distribution system. As compressed air system consultants and troubleshooters, we use these guidelines to design new piping systems and to analyze existing system performance and opportunities for improvement.

Interconnects and headers

The interconnecting piping is a critical element that must deliver air to the distribution headers with little pressure loss, if any. This isn't only an energy question. Also ensures the capacity controls will have sufficient effective storage to allow them to react to real demand and translate less air usage to a comparable reduction in input electrical energy.

The main distribution headers not only move air throughout the plant, they also supply the appropriate local storage that ensures the process feeds have adequate entry pressure and flow. The main header system represents storage that supports the operating pressure band for capacity control. You want the pressure drop between compressor discharge and point of use to be significantly less than the normal operating control band (10 psig maximum).

The targets

The objective in sizing interconnecting piping is to transport the maximum expected volumetric flow from the compressor discharge, through the dryers, filters and receivers, to the main distribution header with minimum pressure drop. Contemporary designs that consider the true cost of compressed air target a total pressure drop of less than 3 psi.

Beyond this point, the objective for the main header is to transport the maximum anticipated flow to the production area and provide an acceptable supply volume for drops or feeder lines. Again, modern designs consider an acceptable header pressure drop to be 0 psi.

Finally, for the drops or feeder lines, the objective is to deliver the maximum anticipated flow to the work station or process with minimum or no pressure loss. Again, the line size should be sized for near zero loss. Of course, the controls, regulators, actuators and air motors at the work station or process have re-

quirements for minimum inlet pressure to be able to perform their functions. In many plants, the size of the line feeding a work station often is selected by people who don't know the flow demand and aren't aware of how to size piping.

In our opinion, new air-system piping should be sized according to these guidelines. For a system that doesn't meet the criteria, the cost of modification must be weighed against the energy savings and any improvements in productivity and quality.

Obviously, the lower the pressure drop in transporting air, the lower the system's energy input. Lower header pressure also reduces unregulated air flow (including leaks) by about 1% per psi of pressure reduction.

Eliminate the drop

Most charts show frictional pressure drop for a given flow at constant pressure. Wall friction causes most of this loss, which is usually denominated as pressure drop per 100 ft. of pipe. Similar charts express the estimated pressure loss for fittings in terms of additional length of pipe. When added to the length of straight pipe, the sum is called total equivalent length. These charts reflect the basic calculations for pressure loss, which include:

- Air density at a given pressure and temperature.
- Flow rate.
- Velocity at pipeline conditions.
- The Reynolds number.

Other factors, including a friction factor based on the size and type of pipe.

The calculations and chart data help to identify only the probable minimum pressure drop. Internal roughness and scaling dramatically affect the pipe's resistance to flow (friction loss). Resistance increases with time as the inner wall rusts, scales and collects more dirt. This is particularly true of black iron pipe.

Pressure drop is proportional to the square of the velocity. Any high-volume, intermittent demand produces dramatic pressure drop during peak periods. Ignoring this fact affects every process connected to the header. For more detail, see "The compressed air receiver: The endless question," page 49, *Plant Services*, May 1997 and Appendix 1, Tables and Outline from DOE/CAC Air

Master Training Manual. For a given size pipe:

- At constant pressure, the greater the flow, the greater the loss per foot of pipe.
- At constant flow rate, the lower the inlet pressure, the greater the loss per foot of pipe.
- At any condition, smooth-bore pipe (copper, stainless steel) exhibits lower friction losses.

Air velocity

The most overlooked idea in piping layout and design is air velocity. Excessive velocity can be a root cause of backpressure, erratic control signals, turbulence and turbulence-driven pressure drop.

The British Compressed Air Society suggests that a velocity of 20 fps or less prevents carrying moisture and debris past drain legs and into controls. A velocity greater than 30 fps is sufficient to transport any water and debris in the air stream. Thus, the recommended design pipeline velocity for interconnecting piping and main headers is 20 fps or less, and never to exceed 30 fps. Field testing reveals that, under these conditions, air stream turbulence is generally negligible. Line drops, feed lines or branch lines less than 50 ft. long work well at a velocity of 30 fps, but velocity here should not exceed 50 fps.

Crunching numbers

First, look at the velocity at maximum anticipated flow conditions using the following equation:

$$V = 3.056 * Q/D[+2][+] \text{ (Eqn 1)}$$

Where V = air velocity (in ft/sec)

Q = volumetric flow rate (in cfm)

D = conduit inside diameter (in inches)

Although this method of determining the minimum pipe size on the basis of air velocity is easy, you also must consider that the compressed air volume is expressed in cubic feet per minute of free air, which is the air volume at ambient atmospheric conditions, not the compressed volume.

To adjust the inlet air volumetric flow rate to actual pipeline conditions, you'll need to divide the volume of free air by the compression ratio using the following equation:

$$CR = (P+P[-]a[-])/P[-]a[-] \text{ (Eqn 2)}$$



Where P = line pressure (in psig)

P[-]a[-] = average atmospheric pressure at your elevation (in psi)

Table 1 shows the compression ratio as a function of gauge pressure for a location at sea level, where the atmospheric pressure is 14.7 psi. At higher elevations, the average atmospheric pressure drops and the compression ratio rises. For example, Flagstaff, Ariz., at a 7,000-ft. elevation, has an average atmospheric pressure of about 11 psi. At 100 psig, the compression ratio is equal to 10 (i.e. 111/11).

To determine the pipeline velocity at conditions, merely divide the velocity given in Equation 1 by the compression ratio given in Equation 2. After selecting the minimum pipe size on the basis of velocity, check any long runs for excessive pressure drop using an appropriate drop chart. For example, a velocity of 25 fps in black iron pipe represents about 0.25 psi loss per 100 ft. of run. Although this is a little above the recommended minimum of 20 fps and, depending on the layout, would probably be acceptable from a turbulence standpoint, a high total frictional loss may dictate using a larger pipe.

This might seem to be somewhat complicated at first, but it's the most accurate way to avoid problems in sizing compressed air piping. Once you get the hang of it, it's easy to use.


After carefully selecting a conduit size that eliminates unnecessary loss, be sure to pay the same attention to downstream items, such as quick disconnects, regulators, filters, controls, fittings, number of drops from a given header and number of connections per header, so as not to offset the gains made with the pipe. Good piping performance is not an accident and "it takes planning.

Atlas Copco

So what's the secret behind the pipe?

www.airnet-system.com

866-688-9611



About the Sponsor

Atlas Copco Compressors develops, manufactures, markets, and services oil-free and oil-injected stationary air compressors, air treatment equipment and air management systems.

Atlas Copco has a focus on exceeding customer needs with a culture built on ongoing interaction, long-term relationships, and a commitment to understanding each customer's process and objectives. As a result, every compressed air solution we create helps customers operate with greater efficiency, economy, and productivity.

To better serve our customers, we have operations where our customers do business. Our Eastern, Central, Southern and Western regions each have their own direct Atlas Copco sales and service team, plus we have a nationwide network of Atlas Copco customer centers and authorized contracted independent distributors. We have four manufacturing facilities in the USA, including one in Wisconsin, two in Texas, and our state of the art manufacturing facility, distribution center, parts warehouse, and corporate offices in Rock Hill, S.C.

Satisfying customer needs with ground-breaking integrated compressed air technology, quality air accessories and 24/7 service support enhanced with remote monitoring tools positions Atlas Copco as a leading global compressor manufacturer. Our unwavering commitment is to be First in Mind – First in Choice® for all your compressed air requirements.

The Atlas Copco logo is centered on the page. It features the company name "Atlas Copco" in a stylized, blue, italicized serif font. The logo is flanked by two solid blue horizontal bars, one positioned above the text and one below it.

Atlas Copco Compressors: The Air Auditing Specialists.



Puzzled by rising energy costs? Atlas Copco has a full range of compressed air auditing services available - from simple system diagnostics all the way to ultrasonic leak detection. These services can be performed on any make or model of compressed air system.

A compressed air audit from Atlas Copco will:

- Show your compressor's energy usage.
- Highlight areas where savings could be made.
- Provide you with a payback analysis on any new investments.
- Provide a professional audit report showing your compressed air usage.



Text: Audit and your Zip Code to 79274
Call Us: 866-688-9611
Log On: www.atlascopco.us/mboxusa

Sustainable Productivity

Atlas Copco